







RAPTOR R

Front Assembly

Driveshafts




Modular Assembly



Driveshaft Assembly

RAPTOR R


Chassis Assembly



Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

See Parts List for a complete listing of optional accessories.

REV 230804-R05



*When installing the 9052R extreme heavy duty steel CV driveshafts, replace the 5120A inner stub axle bearing with 5117A.

REV 230804-R05


Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

See Parts List for a complete listing of optional accessories.



RAPTOR R

Transmission Assembly




TRAXXAS

See Parts List for a complete
listing of optional accessories.

REV 230804-R05

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing, however Traxxas cannot be held responsible for typographical or other errors.

Completed Assembly

A perspective line drawing of a completed pickup truck assembly. The drawing shows the truck from a front-three-quarter view, highlighting the cab, the bed, and various components like the hood, fenders, and wheels. The truck is shown without a driver or passenger, emphasizing the vehicle's structure.[illegible]

REV 230804-R05

See Parts List for a complete listing of optional accessories.